
Installing the Expansion I/O Port Unit MZ-80EU

This reference card describes outline of installing the expansion I/O port unit MZ-80EU. For details on setting the MZ-80EU, refer to the Owner's Manual (chapter 3).

- 1) First, turn the MZ-80B power switch off and pull the power plug out of the AC outlet. Remove the two retaining screws on the rear side of the main cabinet.
- 2) Gently lift the upper part of the main cabinet and support it with the supporting arm.
- 3) Open the I/O module access window by removing the two screws holding the window cover panel.
- 4) Insert the expansion I/O port unit MZ-80EU through the opened window.
- 5) Affix the expansion I/O port unit on the inside with two screws and at the window with two screws.
- 6) After the expansion I/O port unit is installed, connect the 40 wire flat cable connector to terminal CN4 of the CPU board and the power supply cable connector to terminal CN7 of the CPU board.

080291-150281